

... have you been trained

The law requires that personnel using this type of equipment in the workplace must be competent and qualified to do so. Training is available at HSS Training Solutions 0845 766 7799

...any comments?

If you have any suggestions to enable us to improve the information within this guide please e-mail your comments or write to the Safety Guide Manager at the address below e-mail: safety@hss.com

©HSS Hire Service Group Ltd 2021 No. 3015/01 Building Two, Think Park, Mosley Road, Trafford Park, Manchester, M17 1FQ

www.hss.com



3015/01

Operating & Safety Guide 3015





RECHARGEABLE LED WORK LIGHT

Easy to set up portable light. Doesn't require generators, power extension leads etc; cutting down set up times and running costs



Code 57126

GENERAL SAFETY

For advice on the safety and suitability of this equipment contact your local HSS Hire.

There is a serious risk of personal injury if you do not follow all instructions laid down in this guide.

The hirer has a responsibility to ensure that all necessary risk assessments have been completed prior to the use of this equipment.

This equipment should only be used by an operator who has been deemed competent to do so by his/her employer.

This equipment should be used by an able bodied, competent adult who has read and understood these instructions. Anyone with either a temporary or permanent disability, should seek expert advice before using it.

Keep children, animals and bystanders away from the work area. Cordon off a NO GO area using cones and either barriers or tape, available for hire from your local HSS Hire.

Never use this equipment if you are ill, feeling tired, or under the influence of alcohol or drugs.

Wear practical, protective clothing, gloves and footwear. Avoid loose garments and jewellery that could catch in moving parts, tie back long hair.

Ensure the work area is well ventilated, if in doubt, ask about ventilation equipment at your local HSS Hire.

Do not work near flammable gases or liquids, petrol or paint thinner fumes for example. **Keep combustible materials at a safe distance** – at least 5m.

Always switch off and unplug the charger when not in

Never carry or pull the charger by its power supply cable.

Check the condition of the equipment before use. If it shows signs of damage or excessive wear, return it to your local HSS Hire.

ELECTRICAL SAFETY

The battery charger is designed to plug straight into a standard 240V 13A power socket.

RCD Never charge the unit in a hazardous

environment. Wet environment poses numerous risks including electrocution.

To reduce the risk of electric shock, use a suitable RCD (Residual Current-Operated Device) available from your local HSS Hire, or power the charger from a mains circuit with a built-in RCD.

Any identified faults report to HSS, never try to repair the light yourself.

GETTING STARTED

Never use the Rechargeable LED Work Light until you have fully read and understood this User Guide and the machine has been properly set up using the information it contains.

CHARGING

The LED Work Light is suitable and can be charged using a 240 Volt 50Hz mains supply.

To charge the light ensure that it is placed on a firm, level surface. Open the lid on the side box and take out the 240 volt charging plug and cable. Place the plug into a 240 volt mains supply socket.

The battery life indication is displayed on the front panel 100%/75%/50%/25% charge indication lamps ensure the light is switched off when charging. Full recharge time is 8-10 hours.

To ensure optimum battery life the light must not be left in a discharged condition. It is recommended that the battery is charged every 24 hours to avoid damage.

IDENTIFIER



Charger Cable

Power On/Off



Battery Status Display Light Output Hi/Med/Low

BASIC TECHNIQUES

When setting up the LED Rechargeable Work Light the on/off switch is located on the front panel.

Press the switch to the ON position

Select the required light output HI/MED/LOW

Ensure you have battery life by observing the battery life indicator lamps.

EOUIPMENT CARE

Never push the equipment beyond its design limits. If it will not do what you want with reasonable ease and speed, assume you have the wrong equipment for the job. Contact your local HSS Hire for advice.

If the lamp fails, do not attempt to replace or fix them, contact your local HSS Hire for advice.

If the battery is discharged it must be recharged within 24 hours to avoid battery damage.

Keep the equipment clean - you will find this less of a chore if you clean it regularly, rather than wait until the end of the hire period.

When not in use, store the equipment somewhere clean, dry and safe from thieves.

FINISHING OFF

Switch the lamp OFF, coil up the 240 Volt charger cable and place it back in the storage box and close the lid

Give the light a clean and prepare for it to be returned to HSS.









Know Your Symbols

HSS have created clear Icons to inform the hirer of their responsibilities towards the safe use of hire equipment.

These are designed to reduce the amount of different safety information labels required for each product for hire.

General use PPE / Warning

Clearly marked minimum PPE will be visible on all equipment,



Correct PPE



HAV Hand Arm Vibration



Danger Rotating blade



Danger Hot exhaust



Danger Electric shock



Caution Abrasive Wheel



Caution Finger trap

Fuel and Supply Types







Di



2t 2 - Stroke Petrol



Electric

Safe Procedures

All hirers must understand and respect the safe procedures of all equipment.

It is the responsibility of the hirer to maintain and return the equipment in a clean condition and good working order.



Ro Read OPS Guide



Outdoor Use only



Heavy Lifting



Cd Check Oil daily



Cf Check Fuel daily



Cw Check Water daily



Bc Battery Care



Sh Safe Height Working



SWI Refer to Data Plate



Check Power Voltage Data Plate

Electrical Safety

Safe wiring procedures.



Ea Must be Earthed Class 1



Doi Double Insulated Class 2



EnlEarth Live Neutral
Wire Coding

Return Responsibility

Charges apply to equipment returned dirty and damaged.



CC Cleaning Charge



